

Sheet B



Slide out draw from underneath sofa.



Remove top board.



Insert side upright pieces.



Insert end upright pieces.

Sheet B



Insert top board into recess, slide drawer back into sofa until it hits its stop.



Remove back cushion from sofa and lower back board.



**Lower both cushions into place.
If requiring two singles pull drawer away from sofa.**